Version: V1.00.001 Revised date: 11-15-2022

Trademark Information

Copyright © 2022 by LAUNCH TECH CO., LTD (also called LAUNCH for short). All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of LAUNCH.

Statement: LAUNCH owns the complete intellectual property rights for the software used by this product. For any reverse engineering or cracking actions against the software, LAUNCH will block the use of this product and reserve the right to pursue their legal liabilities.

Disclaimer of Warranties and Limitation of Liabilities

All information, illustrations, and specifications in this manual are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice. We shall not be liable for any direct, special, incidental, indirect damages or any economic consequential damages (including the loss of profits) due to the use of the document.

Using This Manual

This manual contains device usage instructions.

Some illustrations shown in this manual may contain modules and optional equipment that are not included in your system.

The following conventions are used.

Bold Text

Bold text is used to highlight selectable items such as buttons and menu options.

Example:

Тар **ОК**.

Notes and Important Messages

Notes

A NOTE provides helpful information such as additional explanations, tips, and comments.

Example:

🛃 Note: Remember to remove the VCI connector from the vehicle's DLC after use.

Warning

Warning indicates a hazardous situation which, if not avoided, could result in minor or moderate injury to the operator or to bystanders.

Example:

A Warning: Retrieving and using DTCs for troubleshooting vehicle operation is only one part of an overall diagnostic strategy. Never replace a part based only on the DTC definition. Each DTC has a set of testing procedures, instructions and flow charts that must be followed to confirm the location of the problem. This information can be found in the vehicle's service manual.

Danger

Danger indicates an imminently or potentially hazardous situation which, if not avoided, could result in death or serious injury to the operator or to bystanders.

Example:

A Danger: If you must drive the vehicle in order to perform a troubleshooting procedure, always have a second person help you. Trying to drive and operate the diagnostic tool at the same time is dangerous, and could cause a serious traffic accident.

Illustrations

Illustrations used in this manual are samples, the actual testing screen may vary for each vehicle being tested. Observe the menu titles and on-screen instructions to make correct option selection.

Important Safety Precautions

To avoid personal injury, property damage, or accidental damage to the product, read all of the information in this section before using the tool.

🛕 DANGER

- When an engine is operating, keep the service area well-ventilated or attach a building exhaust removal system to the engine exhaust system. Engines produce various poisonous compounds (hydrocarbon, carbon monoxide, nitrogen oxides, etc.) that cause slower reaction time and result in death or serious personal injury.
- Please use the included battery and power adaptor. Risk of explosion if the battery is replaced with an incorrect type.
- DO NOT attempt to operate the tool while driving the vehicle. Have second personal operate the tool. Any distraction may cause an accident.

🛕 WARNING

- · Always perform automotive testing in a safe environment.
- Do not connect or disconnect any test equipment while the ignition is on or the engine is running.
- Before starting the engine, put the gear lever in the Neutral position (for manual transmission) or in the Park (for automatic transmission) position to avoid injury.
- NEVER smoke or allow a spark or flame in vicinity of battery or engine. Do
 not operate the tool in explosive atmospheres, such as in the presence of
 flammable liquids, gases, or heavy dust.
- Keep a fire extinguisher suitable for gasoline/chemical/electrical fires nearby.
- Wear an ANSI-approved eye shield when testing or repairing vehicles.
- Put blocks in front of the drive wheels and never leave the vehicle unattended while testing.
- Use extreme caution when working around the ignition coil, distributor cap,

ignition wires and spark plugs. These components create hazardous voltage when the engine is running.

- To avoid damaging the tool or generating false data, please make sure the vehicle battery is fully charged and the connection to the vehicle DLC (Data Link Connector) is clear and secure.
- Automotive batteries contain sulfuric acid that is harmful to skin. In operation, direct contact with the automotive batteries should be avoided. Keep the ignition sources away from the battery at all times.
- Keep the tool dry, clean, free from oil, water or grease. Use a mild detergent on a clean cloth to clear the outside of the equipment when necessary.
- Keep clothing, hair, hands, tools, test equipment, etc. away from all moving or hot engine parts.
- Store the tool and accessories in a locked area out of the reach of children.
- Do not use the tool while standing in water.
- Do not expose the tool or power adapter to rain or wet conditions. Water entering the tool or power adaptor increases the risk of electric shock.
- This tool is a sealed unit. There are no end-user serviceable parts inside. All internal repairs must be done by an authorized repair facility or qualified technician. If there is any inquiry, please contact the dealer.
- Keep the tool far away from magnetic devices because its radiations can damage the screen and erase the data stored on the tool.
- Do not attempt to replace the internal rechargeable lithium battery. Contact the dealer for factory replacement.
- Do not disconnect battery or any wiring cables in the vehicle when the ignition switch is on, as this could avoid damage to the sensors or the ECU.
- Do not place any magnetic objects near the ECU. Disconnect the power supply to the ECU before performing any welding operations on the vehicle.
- Use extreme caution when performing any operations near the ECU or sensors. Ground yourself when you disassemble PROM, otherwise ECU and sensors can be damaged by static electricity.
- When reconnecting the ECU harness connector, be sure it is attached firmly, otherwise electronic elements, such as ICs inside the ECU, can be damaged.
- Because there are various procedures, techniques, tools, and parts for servicing vehicles, as well as the skill of the person doing the service work, the technician must be well knowledgeable of the vehicle and the system

being tested.

- The vehicle parts and the X-PROG 3 components are welded at a constant temperature.
- When welding vehicle parts with the X-PROG 3 components, the unit is powered off and is grounded.

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

TABLE OF CONTENTS

1 Introduction	1
1.1 Product Profile	1
1.2 Components & Controls	2
1.2.1 Display Tablet	2
1.2.2 VCI Connector	4
1.3 Technical Parameters	6
1.4 Package List	6
2 Initial Use	8
2.1 Charging & Turning On	
2.2 Screen Layout	
2.3 Basic Gestures	
2.4 Change System Language	9
2.5 Adjust Brightness	9
2.6 Set Standby Time	9
2.7 Network Setup	10
3 Getting Started	11
3.1 Register & Update	11
3.2 Job Menu	13
3.3 Diagnostics Toolbar	
4 Connections	16
4.1 Preparation	16
4.2 Vehicle Connection	16
4.2.1 OBD II vehicle Connection	17
4.2.2 Non-OBD II vehicle Connection	17
5 Key Immobilizer & Immobilizer Programming	19
5.1 Key Immobilizer (IMMO)	19
5.1.1 Vehicle connection	19
5.1.2 Immobilizer operations	20

5.2 Immobilizer Programming (IMMO PROG)	25
6 Diagnosis	26
6.1 Intelligent Diagnose	
6.2 Local Diagnose	29
6.2.1 Health Report (Quick Test)	34
6.2.2 System Scan	37
6.2.3 System Selection	38
6.3 Remote Diagnose	46
6.3.1 Add Friends	47
6.3.2 Start Instant Messaging	49
6.3.3 Launch Remote Diagnosis (Device-To-Device)	50
6.3.4 Launch Remote Diagnosis (Device-To-PC)	53
6.4 Feedback	55
6.5 Diagnostic History	56
7 Service (Reset) Function	
7 Service (Reset) i unction	
7.1 Oil Reset Service	
	57
7.1 Oil Reset Service	57 57
7.1 Oil Reset Service 7.2 Electronic Parking Brake Reset	57 57 57
7.1 Oil Reset Service7.2 Electronic Parking Brake Reset7.3 Steering Angle Calibration	
7.1 Oil Reset Service7.2 Electronic Parking Brake Reset7.3 Steering Angle Calibration7.4 ABS Bleeding	
 7.1 Oil Reset Service 7.2 Electronic Parking Brake Reset	57 57 57 58 58 58 58 58
 7.1 Oil Reset Service	57 57 57 58 58 58 58 58 58 58
 7.1 Oil Reset Service	57 57 57 58 58 58 58 58 58 58 58 58
 7.1 Oil Reset Service	57 57 57 58 58 58 58 58 58 58 58 59 59
 7.1 Oil Reset Service 7.2 Electronic Parking Brake Reset 7.3 Steering Angle Calibration 7.4 ABS Bleeding 7.5 Tire Pressure Monitor System Reset 7.6 Gear Learning 7.7 Injector Coding 7.8 Battery Maintenance System Reset 7.9 Diesel Particulate Filter (DPF) Regeneration 	57 57 57 58 58 58 58 58 58 58 59 59 59
 7.1 Oil Reset Service	57 57 57 58 58 58 58 58 58 58 59 59 59 59 59
 7.1 Oil Reset Service 7.2 Electronic Parking Brake Reset 7.3 Steering Angle Calibration 7.4 ABS Bleeding 7.5 Tire Pressure Monitor System Reset 7.6 Gear Learning 7.7 Injector Coding 7.8 Battery Maintenance System Reset 7.9 Diesel Particulate Filter (DPF) Regeneration 7.10 Electronic Throttle Position Reset 7.11 EGR Adaption 	57 57 58 58 58 58 58 58 58 59 59 59 59 59 59 59
 7.1 Oil Reset Service 7.2 Electronic Parking Brake Reset 7.3 Steering Angle Calibration 7.4 ABS Bleeding 7.5 Tire Pressure Monitor System Reset 7.6 Gear Learning 7.7 Injector Coding 7.8 Battery Maintenance System Reset 7.9 Diesel Particulate Filter (DPF) Regeneration 7.10 Electronic Throttle Position Reset 7.11 EGR Adaption 7.12 Gearbox Matching 	57 57 58 58 58 58 58 58 58 59 59 59 59 59 59 59 59 59 59 59 59

8 Software Update	61
8.1 Update Diagnostic Software & APP	61
8.2 Update IMMO&IMMO PROG Software	61
8.3 Renew Subscription	62
9 Other Modules	64
9.1 Toolbox	64
9.1.1 BST360 (Battery Tester)	64
9.1.2 Videoscope	64
9.1.3 S2-2 Sensorbox	64
9.1.4 S2-2 Multimeter	64
9.2 User Info	64
9.2.1 My Report	64
9.2.2 VCI	65
9.2.3 VCI Management	65
9.2.4 Activate VCI	65
9.2.5 Firmware Fix	65
9.2.6 My Order	65
9.2.7 Subscription Renewal Card	66
9.2.8 Profile	66
9.2.9 Change password	66
9.2.10 Settings	66
9.2.11 Diagnostic Software Clear	72
10 FAQ	73

1 Introduction

1.1 Product Profile

It inherits from LAUNCH's advanced diagnosing technology and is characterized by covering a wide range of vehicles, featuring powerful functions, and providing precise test result.

Through the simple wireless/USB communication between VCI (Vehicle Communication Interface) device and the display tablet, it achieves full car model and full system vehicle trouble diagnosis.

For X-431 PRO (IMMO ELITE), it covers basic diagnostic functions, including read version information, read DTCs (Diagnostic Trouble Codes), clear DTCs and read data stream.

For X-431 PRO (IMMO PLUS), it covers full diagnostic function, including read version information, read DTCs (Diagnostic Trouble Codes), clear DTCs, read data stream, actuation test, matching, coding and programming etc.

It has the following features:

- <u>IMMO (Immobilizer)</u>: This function enables you to perform the anti-theft key matching function, so that the immobilizer control system on the car identifies and authorizes remote control keys to normally use the car.
- <u>IMMO PROG (Immobilizer Programming)</u>: This function allows you to read transponder data and generate exclusive keys, and read/write on-board EEPROM chip data and MCU/ECU chip data. X-PROG 3 is required when performing this function.
- Intelligent Diagnose: This module allows you to use the VIN information of the currently identified vehicle to access its data (including vehicle information, historical diagnostic records) from the cloud server to perform quick test, eliminating guesswork and step-by-step manual menu selection.
- <u>Local Diagnose</u>: Follow the on-screen prompts to start diagnostic session step by step.
- <u>Remote Diagnose</u>: This option aims to help repair shops or technicians launch instant messaging and remote diagnosis, making the repair job getting fixed faster.

- Service Function: Includes all kinds of common maintenance and reset items.
- <u>TPMS:</u> Configures the tool as a professional Tire Pressure Monitoring System (TPMS) service tool. It needs to work with the TSGUN device (sold separately) to perform all kinds of various TPMS functions.
- <u>Diagnostic History</u>: This function provides a quick access to the tested vehicles and users can choose to view the test report or resume from the last operation, without starting from scratch.
- <u>Feedback</u>: Enables you to submit the vehicle issue to us for analysis and troubleshooting.
- One-click Update: Lets you update your diagnostic software online.
- Vehicle Coverage: Quick dial to view the vehicle models that the tool covers.
- <u>Add-on modules</u>: Optional. BST 360 Battery Tester, S2-2 Sensorbox, Multimeter and Videoscope etc. are available as add-on modules, extending the functions of the tool.

1.2 Components & Controls

There are two main components to the diagnostic system:

- Display Tablet the central processor and monitor for the system (See Chapter 1.2.1).
- VCI Device the device for accessing vehicle data (See Chapter 1.2.2).

1.2.1 Display Tablet

The tablet acts as the central processing system, which is used to receive and analyze the live vehicle data from the VCI device and then output the test result.



In Off mode, press it for 3 seconds to turn the tablet on.

In On mode:

- Press it once to activate the LCD if the LCD is off. Press it once to turn off the LCD if the LCD lights up.
 - Press and hold it for 3 seconds to turn it off.
 - Press and hold it for 8 seconds to perform forced shutdown.

5 LCD Screen



- 6 Speakers
- 7 Rear Camera
- 8 Microphone

1.2.2 VCI Connector

The VCI connector works as a vehicle communication interface device, which is used to connect to the vehicle's DLC (Data Link Connector) socket via the diagnostic cable to read the vehicle data and then send it to the tablet.

₽ Note: Remember to remove the VCI connector from the vehicle's DLC after use.



1	Power indicator	Illuminates red while the VCI is powered up.
2	Vehicle indicator	Illuminates green and flashes when the VCI is communicating with the vehicle.
3	I/O indicator	 Illuminates blue when the VCI is communicating with the tablet via Bluetooth. Illuminates red when the VCI is connected to the tablet via USB cable.
4	DB-15 diagnostic connector	Connects on vehicle's OBD II DLC via the diagnostic cable.
5	USB port	Connects the VCI to the tablet to perform vehicle diagnosis via USB cable.

1.3 Technical Parameters

Display Tablet

Operating system	Android
Memory	4GB
Storage	64GB
Screen	8 inch capacitive touch screen with a resolution of 1280 x 800 pixels
Camera	Rear-facing 8.0MP camera
Connectivity	Wi-Fi (802.11a/b/g/n/ac)Bluetooth
Working temperature	0°C ~ 50°C
Storage temperature	-20℃ ~ 70℃
VCI Connector	
Working voltage	9 ~18V
Power consumption	≤2.0W
Working temperature	-10℃ ~50℃
Relative humidity	20% ~ 90%

1.4 Package List

The following packing list is for reference purpose only. For different destinations, the accessories may vary. For details, please consult from the seller or check the packing list supplied with this tool together.

No.	ltem	Descriptions	Qt.
1	Display tablet	Indicates the test result.	1
2	VCI connector	A device for accessing vehicle live	1

		data.	
3	Diagnostic cable	Connects the VCI connector to vehicle's OBD II diagnostic socket.	1
4	Password envelope	A piece of paper bearing the product Serial Number and Activation Code for product registration.	1
5	X-PROG 3 immobilizer programmer kit	Includes the X-PROG 3 immobilizer programmer and the accessory.	1
6	Power adaptor	Charges the tablet via AC outlet.	(Optional)
7	Type-A to Type-C USB cable	 Connects the diagnostic tool to AC outlet / PC for charging / data exchange. Connects the VCI connector to the diagnostic tool to perform vehicle diagnosis. 	1
8	Battery clamps cable	Supplies power to the non-16pin connector from the vehicle's battery.	(Optional)
9	Cigarette lighter cable	Supplies power to the non-16pin connector from the cigarette lighter receptacle.	(Optional)
10	OBD I adaptor box	Connects the diagnostic cable and non-16pin adaptor cable.	(Optional)
11	Non-16pin adaptor cable kit	For different vehicle diagnostic socket, it may be necessary to use one of the non-16pin connectors included within the kit. For detailed non-16pin connectors, please check the package box.	(Optional)

2 Initial Use

2.1 Charging & Turning On

- 1. Use the included power adaptor to charge the tablet.
- 2. After charging is complete, press the POWER button to turn the tablet on. The system starts initializing and then enters the home screen.

Vote: If the battery remains unused for a long period of time or the battery is completely discharged, it is normal that the tool will not power on while being charged. Please charge it for a period of 5 minutes and then turn it on.

Warning: Please use the included power adaptor to charge your tool. No responsibility can be assumed for any damage or loss caused as a result of using power adaptors other than the one supplied.

Press [POWER] for 3 seconds, an option menu will pop up on the screen. Tap **Power off** to turn the tool off.

2.2 Screen Layout

There are five on-screen buttons available on the bottom of the screen.

Home: Navigates to the Android's home screen.

Recent App: Views the running applications.

VCI Connection: Shows whether the VCI device is properly connected or not.

Screenshot: Captures the current screen.

Back: Returns to the previous screen.

2.3 Basic Gestures



Single-tap: To select an item or launch a program.



Double-tap: To zoom in so that the text on a webpage appears in a column that fits your device's screen.



Long press: Tap and hold on the current interface or area until a contextual menu pops up on the screen, and then release it.



Slide: To jump to different pages.



Drag: Tap the application icon and drop it to other location.



Spread apart/pinch together: To zoom in manually, place two fingers on the screen and then spread them apart. To zoom out, place two fingers apart on the screen and then pinch them together.

2.4 Change System Language

The tool supports multiple system languages. To change the language of the tool, please do the following:

- 1. On the home screen, tap Settings -> System -> Language & input -> Languages.
- 2. Tap Add a language, and then choose the desired language from the list.
- 3. Tap and hold the desired language and drag it to the top of the screen and then release it, the system will change into the target language.

2.5 Adjust Brightness

 \mathbf{E} Note: Reducing the brightness of the screen is helpful to conserve the battery power.

- 1. On the home screen, tap Settings -> Display -> Brightness level.
- Drag the slider to adjust it.

2.6 Set Standby Time

If no activities are made within the defined standby period, the screen will be

locked automatically and the system enters sleep mode to save power.

- 1. On the home screen, tap Settings -> Display -> Advanced -> Sleep.
- 2. Choose the desired sleep time.

2.7 Network Setup

The tablet has built-in Wi-Fi that can be used to get online. Once you're online, you can register your tool, surf the Internet, get apps, send email, launch the remote diagnosis, and check for software updates etc.

- 1. On the home screen, tap Settings -> Network & Internet -> WLAN.
- Slide the Wi-Fi switch to ON, the tablet starts searching for available wireless networks.
- 3. Select a wireless network,
 - If the chosen network is open, the tablet will connect automatically.
 - If the selected network is encrypted, a network password will need to be entered.
- 4. When **Connected** appears, it indicates the Wi-Fi connection is complete.

Vote: When Wi-Fi is not required, this should be disabled to conserve battery power.

3 Getting Started

For new users, you will need to experience a user registration process before getting started.

3.1 Register & Update

Follow the steps below to proceed registration and update:

Tap the application icon on the home screen to launch it, and then tap **Login** to enter the login interface of diagnosis software.

Owner login		
01		
0		
	LOGIN	
Retrieve Password	New Registration	Technician login

(If you are a new user, follow A to proceed.)

(If you have registered to be a member, go to B to login the system directly.)

(If you have bound a sub-account to this tool, go to C to login the system.)

(In case you forgot password, refer to D to reset a new password.)

A. If you are a new user, tap New Registration to enter the sign-up page.



Fill in the information in each field (Items with * must be filled). After inputting,

tap Register, the following screen will appear:



Input the 12-digit Product Serial Number and 8-digit Activation Code (can be obtained from the password envelope), and then tap **Activate**.



Tap **Yes** to navigate to the update center to update all available software. Tap **No** to ignore it. In this case, follow Chapter 8 to check for updates.



After the registration is successfully complete, the wireless communication between the tablet and the VCI device is automatically established and user has no need to configure it again.

B. If you have registered to be a member, input your name and password, and then tap **Login** to enter the main menu screen directly.

Note: The tablet has an auto-save function. Once the username and password are correctly entered, the system will automatically store it. Next time you login the system, you will not be asked to input the account manually.

- <u>C.</u> If you have created a sub-account or bound an existing account to the tool, tap **Technician login** to login. For more details on sub-accounts, refer to Chapter 9.2.10.
- D. If you forgot the password, tap Retrieve password and then follow on-screen instructions to set a new password.

3.2 Job Menu

It mainly includes the following items:

Name	Description	
ІММО	This function enables you to perform the anti-theft key matching function, so that the immobilizer control system on the car identifies and authorizes remote control keys to normally use the car.	
IMMO PROG	 Read transponder data (including Mercedes Benz infrared smart key), and generate exclusive keys. Read/write on-board EEPROM chip data, and read/write MCU/ECU chip data. 	
Intelligent Diagnose	 Obtain vehicle data from the cloud server to perform quick test via reading VIN, to avoid various defects resulting from step-by-step menu selection. Check the historical repair records online. 	
Local Diagnose	Diagnose a vehicle manually.	

Remote Diagnose	This option aims to help repair shops or technicians launch instant messages and remote diagnosis, making the repair job getting fixed faster.	
Service Function	Perform commonly used repair & maintenance services.	
TPMS	Configures this tool as a professional TPMS (Tire Pressure Monitoring System) service tool. It needs to work with the TSGUN device (sold separately) to perform all kinds of various TPMS functions.	
Diagnostic History	Access the diagnostic reports from the previously tested vehicles.Resume the previous operation without starting from scratch.	
Feedback	Feedback the recent 20 diagnostic logs for issue analysis.	
Software Update	Update vehicle diagnostic software and APK.	
Info Center	Includes product information and repair data etc.	
Vehicle Coverage	View all the vehicle models that the tool covers.	
User Info	To manage VCI, reports, change password, configure wireless Wi-Fi printer, configure system settings and logout etc.	
Other Modules	Includes some add-on modules (such as Videoscope and BST360 etc).	

3.3 Diagnostics Toolbar

The diagnostics toolbar contains a number of buttons that allow you to print the displayed data or make other controls. It is displayed on the upper right corner of the screen and goes through the whole diagnostic session. The table below provides a brief description for the operations of the diagnostics toolbar buttons:

	Diagnostic Trouble	Code 🛉 🖻 🗗
Name	Button	Description
Home		Returns to Job menu screen.
Print		Tap to print the current screen. Before printing, you need to configure the wireless printer following the steps described in Chapter 9.2.10.
Exit	ŀ	Exits the diagnostic application.

4 Connections

4.1 Preparation

- The vehicle ignition is turned on.
- The vehicle battery voltage range is 11-14 volts.
- The throttle is in the closed position.
- Find DLC location.

The DLC(Data Link Connector) is usually located 12 inches from the center of the instrument panel, under or around the driver's side for most vehicles. For some vehicles with special designs, the DLC location may vary. Refer to the following figure for location.



- A. Opel, Volkswagen, Audi
- B. Honda
- C. Volkswagen
- D. Opel, Volkswagen, Citroen
- E. Changan

F. Hyundai, Daewoo, Kia, Honda, Toyota, Nissan, Mitsubishi, Renault, Opel, BMW, Mercedes-Benz, Mazda, Volkswagen, Audi, GM, Chrysler, Peugeot, Regal, Beijing Jeep, Citroen and other most popular models

If the DLC cannot be found, refer to the vehicle's service manual for the location.

4.2 Vehicle Connection

The method used to connect the VCI device to a vehicle's DLC depends on the vehicle's configuration as follows:

• A vehicle equipped with an OBD II management system supplies both

communication and 12V power through a standardized DLC.

 A vehicle not equipped with an OBD II management system supplies communication through a DLC connection, and in some cases supplies 12V power through the cigarette lighter receptacle or a connection to the vehicle battery.

4.2.1 OBD II vehicle Connection

Use the included diagnostic cable to connect the VCI to the vehicle's DLC port.



4.2.2 Non-OBD II vehicle Connection

For non-OBDII vehicle, proceed as follows:



Note: If the pin of the DLC is damaged or the DLC has insufficient power, you can get power via either of the following methods:

A. Battery Clamps Cable (optional):



B. Cigarette Lighter Cable (optional):



If you choose to perform vehicle diagnosis via data cable, connect one end of the data cable into the VCI, and the other end into the USB port of the tablet.

5 Key Immobilizer & Immobilizer Programming

5.1 Key Immobilizer (IMMO)

This function enables you to perform the anti-theft key matching function, so that the immobilizer control system on the car identifies and authorizes remote control keys to normally use the car.

It needs to be performed in the following cases:

When the ignition switch key, ignition switch, combined instrument panel, ECU, BCM, or remote control battery is replaced.

5.1.1 Vehicle connection

1). For most vehicles, just use the included diagnostic cable to connect the VCI to the vehicle's DLC port.



- 2). For other vehicles (including but not limited to the Mercedes Benz, Volkswagen, BMW and Porsche), the X-PROG 3 is required.
- A: DB15 to OBD16 diagnostic cable
- B: Main diagnostic cable included with the X-PROG 3 immobilizer programmer



5.1.2 Immobilizer operations

Here we take the BMW for example to demonstrate how to perform the functions of key adding and all lost for BMW CAS4/CAS4+ Anti-theft system module.

1) Tap IMMO and select BMW to enter the software.

marks have \$20 a down		E 19.974
Automatically Search	Manually Select	
Codiing/Program	Special Function	
Function Help	ADAS Calibration	
Anti-Theft System		
RAWN GT SIGN ADMINISTEE VIII WEARPECKIECSTRES		

2) Tap **OK**.



 Enter the Anti-Theft System, follow the illustration below to connect the VCI, vehicle and X-PROG3/X-PROG (*needs to purchased separately) to perform the next step.



4) If you don't know the type of the Anti-Theft System, tap **Intelligent Mode** to enter.

IMMO Engine System
Engine System

5) Tap CAS4/CAS4+ Anti-Theft System, the following screen will appear:

ECU Information Read ISN Preprocessing Key Learn Replace Immobilizer Data Mileage F	
Replace Immobilizer Data Mileage F	leset
Key Status MCU Ope	ration
IMAW GT 3359 FORME 2011 VIEL WEATER(CS) EC2217810	

6) Tap **Preprocessing** to perform Read Anti-Theft data, Key Matching and more. If it has already been preprocessed, here you can perform the relevant functions. The ECU will be upgraded in this process, and files need to be downloaded online.



7) Make sure that vehicle power supply voltage is not lower than 13V and stable, and then tap **Yes** to start preprocessing.



8) After preprocessing succeeded, tap OK.

Preprocessing			
Preprocessing Succeeded, Restore Code Successfully !			
ок			

9) Return to the function menu and tap Key Learning.

Biddy 4:00 10 + April 17mil Terran		(E) (1 ###
ECU Information	Read (SN (Initial Serial Number)	
Preprocessing	Key Learning	
Replace Immobilizer Data	Mileage Reset	
Key Status	MCU Operation	
BMW GT \$35 x0mw 2011 V1N WBASP2C\$18C337850		

10) After the key information successfully read, select the unused key position and tap **Key Generated By Ignition Switch**.

BMW V50.70 > Anti-Theft Syster	n			E 11.5	
Key Position	Key ID		Key Status		
Key 1	FFFFFFF		Unused		
Key 2	A281AA32	A281AA32		Used	
Key 3	FFFFFFF		Unused		
Key 4	FFFFFFFF		Unused		
Key 5	FFFFFFFF		Unused		
Key 6	FFFFFFFF		Unused		
Key 7	FFFFFFF		Unused		
Key Generated B	y Ignition Switch	Key Generated By Program		Erase Key 1	

11) Read and display the password, and tap **OK**.



12) Place a new key close to vehicle coil, tap **OK**, and wait for the key to generate.



13) After the dealer key is successfully generated, please try to start the vehicle.



14) Now the key matching is finished and the new key is ready for use.



5.2 Immobilizer Programming (IMMO PROG)

The X-PROG 3 is required when performing this operation.

It has the following functions:

- 1). Read transponder data (including Mercedes Benz infrared smart key), and generate exclusive keys.
- 2). Read/write on-board EEPROM chip data, and read/write MCU/ECU chip data.

For more detailed operations, refer to the User Manual of the X-PROG 3.

6 Diagnosis

6.1 Intelligent Diagnose

Through simple Bluetooth communication between the display tablet and VCI, you can easily get the VIN (Vehicle Identification Number) information of the currently identified vehicle. Once the VIN is successfully identified, the system will retrieve it from the remote server and then guide you to vehicle information page without the necessity of step-by-step manual menu selection.

The vehicle information page lists all historical diagnostic records of the vehicle, which lets the technician have a total command of the vehicle faults. In addition, a quick dial to local diagnose and diagnostic function are also available on this page for reducing the roundabout time and increasing productivity.

🛃 Notes:

- Before using this function, please make sure the VCI is properly connected to the vehicle's DLC. For detailed connection, see Chapter 4.2.
- A stable network connection is required for this function.
- 1. Tap **Intelligent Diagnose** on the Job menu screen to start pairing with the VCI.
- 2. After pairing is complete, the tablet starts reading the vehicle VIN.
- A. <u>If the VIN can be found from the remote server database</u>, the following screen will appear:



• Tap Diagnostic to start a new diagnostic session.

 Tap Maintenance record to view its historical repair record. If there are records available, it will be listed on the screen in sequence of date. If no records exist, the screen will show "No Record".

Scan History	L.			
2020 05/14	Number of diagnostic systems:3	Quantity of 01 cara	14;33:47	View Record
2020 03/12	Number of diagnostic systems:0	Quantity of DTQx12	1017/02	View Record
	Number of diagnostic systems:3	Quantity of DTCard	10.16.00	View Record
2020 03/10	Number of diagnostic systems:4	Quantity of DTEarth	16:39:54	View Record
Annota 马音达2.2 IN LVSFDAMA3	007			Quick Access

- Tap View Record to view the details of the current diagnostic report.
- To perform other functions, tap **Quick access** to directly go to the function selection screen. Choose the desired one to start a new diagnostic session.
- B. <u>If the tablet failed to access the VIN information</u>, the following screen will appear:



- Tap the input field to directly, tap **OK**. If the VIN exists on the remote server, the system will enter the diagnostic function selection screen.
- Tap 🔚 to launch the VIN recognition module.


Place the VIN inside the viewfinder rectangle to scan it. The most recognizable location for this number is in the top left corner on the vehicle's dashboard. Other locations include the driver's door or post, and the firewall under the hood.

- Tap (to switch the display mode of the screen.
- Tap 🔀 to turn the camera flash on.
- Tap C to choose it from the record list if the VIN of the vehicle has been scanned before.
- Tap *i* to input the VIN manually if the tablet has failed to identify the VIN of the vehicle.
- Tap to scan the VIN barcode. If the VIN barcode cannot be recognized, please manually input the VIN.
- Tap A to scan the VIN character. If the VIN character cannot be recognized, please manually input the VIN.

After scanning, the screen will automatically display the result.



- If the VIN scanned is incorrect, tap the result field to modify it and then tap OK.
- To scan it again, tap REPEAT.

If the VIN exists on the remote server, the system will enter the diagnostic function selection screen.

6.2 Local Diagnose

In this mode, you need to execute the menu-driven command and then follow the on-screen instruction to proceed.

Tap Local Diagnose to enter the vehicle selection page.

Local Diagnose	Common	American Europ	and Arian	Chinaira	
Deservative for DEMO	EOBD/OBDII		Degeneration for	ALFA ROMEO	Descented by ASTON MARTIN
AUDI	BAIC	Departments BENTLEY	Biggenessing for	BMW	BRILLIANC E
Bugartin for	BUICK	BUICK (CHINA)	Bugernen ho BYD	CADILLAC	CHANGAN

2 approaches are provided for you to access the vehicle diagnostic software. Choose any one of the following ways:

1. VIN SCAN enables you to access it more quickly.

Tap VIN Scan, the following screen will appear:



In this case, camera scan and enter VIN are available.

<u>A. Camera Scan:</u> In this mode, the VCI should be connected to the vehicle's DLC first, and then a Bluetooth communication should be established between the tablet and the VCI.

Tap Camera Scan, a screen similar to the following will appear:



Place the VIN inside the viewfinder rectangle to scan it. The most recognizable location for this number is in the top left corner on the vehicle's dashboard. Other locations include the driver's door or post, and the firewall under the hood.

- Tap (III) to switch the display mode of the screen.
- Tap 🙀 to turn the camera flash on.
- Tap
 to choose it from the record list if the VIN of the vehicle has been

scanned before.

- Tap for input the VIN manually if the tablet has failed to identify the VIN of the vehicle.
- Tap is to scan the VIN barcode. If the VIN barcode cannot be recognized, please manually input the VIN.
- Tap A to scan the VIN character. If the VIN character cannot be recognized, please manually input the VIN.

After scanning, the following screen will appear.

Recognize result	BI 507724
	013077723
WEAFD2TD2Bc307754	orrect olick change VIN
length is limited to 17	onect, click change. virv
REPEAT	-100

If the VIN scanned is incorrect, tap the result field to modify it and then tap **OK**. If the VIN exists on the remote server, the system will navigate to the diagnostic function selection screen directly.

Tap the desired option to perform the corresponding diagnostic function.

B. INPUT VIN: In this mode, you can input the vehicle VIN manually.

Tap Enter VIN, the following screen will appear.

Enter VIN						
	EnterVIN				-	
		loki	-	CLEAR!		
		-	-			

Input the VIN, and tap **OK**, the tablet will automatically identify the vehicle model and directly navigate to the diagnostic function selection menu.

2. Tap a corresponding diagnostic software logo, and then follow the on-screen instruction to access the diagnostic software.

Take Demo (Version 15.32) as an example to demonstrate how to diagnose a vehicle.

1). Select diagnostic software version: Tap the DEMO to go to Step 2.



On-screen Buttons:

<u>Vehicle Coverage</u>: Tap to view the vehicle models that the current diagnostic software covers.

What's new: Tap to view the optimized items and enhancements.

Introduction: Tap to check the software function list.

Note: Tap to read some precautions on using the current diagnostic software.

<u>Search Bluetooth</u>: Tap to search for the available VCI. After the VCI is successfully activated, it will be bound to the user account and paired with the tablet automatically.

🛃 Note: No Bluetooth connection is required for DEMO program.

OK: Tap it to go to next step.

 <u>Select vehicle model (varies with different versions)</u>: Select the desired vehicle model. Here we take **Ford** for example to demonstrate how to diagnose a vehicle.



3). Turn the ignition key to ON: Set the ignition switch to on.

Show Menu			A 0 0
FORD	Chevrolet	TOYOTA.	
	Set ignition Switch To		
	CANCEL	ок	
-			

4). <u>Read vehicle information</u>: After reading the vehicle information, double check if the vehicle information is correct or not. If yes, tap **Yes** to continue.

Show Monu			1 9 P
FORD	Vehicle Infi VHV: 1FTBWJDTVC2B00000 Metel Vev: 2012 Vehicle + F-250 Capacity - 8 21 Empire Type + Power Stoke-Dest Fur Type + Romet Transmission + Auto Is The Vehicle Information Correct	τογοτά	
	NO	YES	
-			

5). Select test item: Select the desired test item to proceed.

Show Menu	A . B
00MD 97532 +FURD	
Health Report	
System Scan	
System Selection	
FORD F-350 2012	
VIN 1FTBW3019CEB00000	

6.2.1 Health Report (Quick Test)

This function varies from vehicle to vehicle. It enables you to quickly access all the electronic control units of the vehicle and generate a detailed report about vehicle health.

On the test item selection screen, tap **Health Report** and turn on the ignition switch, the system will start scanning the ECUs. Once the scanning process is complete, the following screen will appear:

Diagnostic Trouble Code			1	0 P
DEMO V1532 > FORD > Health Traport				
PCM (Powertrain Control Module)			3	Enter
P0401 EGR Valve A Flow Insufficient Detected				Current
P1291 Injector High Side Short To GND Or VBA	TT (Bank1)			Current
P2073 Manifold Absolute Pressure/Mass Air Fi	low-Throttle correla	tion at idle		Current
TCM(Transmission Control Module)			Normal	Enter
ABS(Anti-lock Braking System)			Normal	Enter
RGM (Restraint Control Module)			Normal	Enter
FORD F-350 2012 VIN 1FT8W30T9CE600000	Report	Help	Compare Results	Clear DTCs

The tested system with fault code appears in red and the system functioning properly displays in black (normally).

Warning: Diagnostic Trouble Codes or Fault Codes can be used to identify which engine systems or components that are malfunctioning. Never replace a part based only on the DTC definition. Retrieving and using DTCs for troubleshooting vehicle

operation is only one part of an overall diagnostic strategy. Follow testing procedures (in vehicle's service manual), instructions and flowcharts to confirm the locations of the problem.

On-screen Buttons:

Enter: Tap to enter the diagnostic function selection screen.

(Search): Highlight certain diagnostic trouble code and tap it to retrieve it in the search engine.

Report: Tap to save the diagnostic result as a health report.

Report	t In	formation	
Report Type			
Pre-Repair			
Vehicle Information			
FORD		F-350	0
2012	0	35565 km	0
1FT8W3DT9CEB00000		Longue at	
Report Info			
FORD_1FT8W3DT9CEB0000 4114	00_	AliSystemDTC_202	0051415 0
See.			
SKIP		ок	

Note: Diagnostic report is classified into three categories: Pre-Repair report, Post-Repair report and Diagnostic Scan. No matter which type you saved the report as, the report type will be appended as a tag on the upper right corner of the diagnostic report for easier identification.

Tap \bigvee to select the report type from the option list and input the required information, and then tap **OK**.

Note: To facilitate the comparison of the pre-repair and post-repair reports and get accurate test result, please make sure you saved the right type of the diagnostic report.

To save the report as a common diagnostic report, select Diagnostic Scan.

	More	e In	formation
Shop Name			Telephone
Launch HQ		0	18123979575 0
Address line1			Email
Long gang District	-	0	764080333@gg.com 0
Address line2			Technician Name
City			Customer Name
shenzhen	- 9	0	Eastphyset v Aamer
State	Zip Code		Country
Guangdong Province	518129	0	Afghanistan
SKIP			OK-

Vote: For workshop information, tap the input box to enter it. Alternatively you can also set it in User Info -> Settings -> Shop Information.

Once you configured the information, it will be automatically generated every time you saved the diagnostic report. All vehicle and workshop information will be appended as tags on the diagnostic report.

To ignore the workshop information, tap Skip to go to the report details screen.



On the report details screen, tap **Save** to save it. All diagnostic reports are saved in **Report -> Health Report**.

Help: Tap to view the help information of the selected DTC item.

<u>Compare Results:</u> Tap to select the pre-repair report to compare. By comparison of the pre- and post- repair reports, you can easily identify which DTCs are cleared and which remain unfixed.

Compare Results		4 6 12
DEMO V15.32 > FORD > Headh Trapact	_	
DTC	Post	Pre
PCM (Powertrain Control Module)		~
P0401 EGR Valve A Flow insufficient Detected	Cleared	Found
P1291 Injector High Side Short To GND Or VBATT (Bank1)	Cleared	Found
P2073 Manifold Absolute Pressure/Mass Air Flow-Throttle correlation at Klie	Cleared	Found

- Post indicates DTC status of post-repair.
- · Pre indicates DTC status of pre-repair.

Note: Before performing this function, please make sure that:

- · You have saved a pre-repair report of the currently tested vehicle, and
- You have already made some repairs and service and cleared the DTCs after the pre-repair reported is generated. Otherwise, no differences exist between the pre- and post- repair reports.

Clear DTCs: Tap to clear the existing diagnostic trouble codes.

Note: Clearing DTCs does not fix the problem(s) that caused the code(s) to be set. If proper repairs to correct the problem that caused the code(s) to be set are not made, the code(s) will appear again and the check engine light will illuminate as soon as the problem that cause the DTC to set manifests itself.

6.2.2 System Scan

This option allows you to quickly scan which systems are installed on the vehicle.

On the test item selection screen, tap **System Scan**, the system start scanning the systems. Once the scanning process is complete, the following screen will appear.

Select Test Item	A 0 D
DEMIT V75 32 + FORD + System Sour	
System Name	Result
PCM (Powertrain Control Module)	Equipped
TCM(Transmission Control Module)	Equipped
ABS(Anti-look Braking System)	Equipped
RCM (Restraint Control Module)	Equipped
BCM(Body Control Module)	Equipped
IMMO(immobilizer)	Equipped
APIM (Accessory Protocol Interface Madule)	Equipped
FORD F-350 2012 VN 1-FTEW3D19CEB00000	

Tap the desired system to go to the diagnostic function selection screen. For detailed operations on diagnostic function, please refer to Chapter 6.2.3.

6.2.3 System Selection

This option allows you to manually select the test system and function step by step.

On the test item selection screen, tap **System Selection**, the screen displays as follows:

Show Menu	A 6 B
DEMIT 975-32 + FORD + System Switterbox	
PCM (Powertrain Control Module)	TCM(Transmission Control Module)
ABS(Anti-lock Braking System)	RCM (Restraint Control Module)
BCM(Body Control Module)	[MMO[(mmobilizer]
APIM (Accessory Protocol Interface Module)	PAM (Parking Assist Module)
ICM1 (Information Genier Module)	DDM (Driver Door Module)
DSM (Driver Seat Mindule)	DSP (Digital Signal Processor)
FORD F-1150 2017. Vel 4FT 8/40 TVCE 000000	

Swipe the screen from the bottom to view the vehicle system on the next page.

Tap the target system (take **ECM** for example) to navigate to the diagnostic function selection screen.

Note: Different vehicle has different diagnostic menus.

A. Version Information

This function is used to read the version information of system mode, vehicle VIN, software and ECU.

B. Read Fault Code

This function displays the detailed information of DTC records retrieved from the vehicle's control system.

▲ Caution: Retrieving and using DTCs for troubleshooting vehicle operation is only one part of an overall diagnostic strategy. Never replace a part based only on the DTC definition. Each DTC has a set of testing procedures, instructions and flow charts that must be followed to confirm the location of the problem. This information can be found in the vehicle's service manual.

On the diagnostic function selection screen, tap **Read Fault Code**, the screen will display the diagnostic result.



On-screen Buttons:

<u>Freeze Frame</u>: When an emission-related fault occurs, certain vehicle conditions are recorded by the on-board computer. This information is referred to as freeze frame data. Freeze frame data includes a snapshot of critical parameter values at the time the DTC is set.

Help: Tap to view the help information.

Code Search: Tap to search for more information about the current DTC online.

<u>Report</u>: Tap to save the current data in text format. All reports are saved in **Report -> Health Reports**.

C. Clear Fault Code

This function enables you to erase the codes from the vehicle after reading the retrieved codes from the vehicle and certain repairs have been carried out. Before performing this function, make sure the vehicle's ignition key is in the ON position with the engine off.

Clearing DTCs does not fix the problem(s) that caused the code(s) to be set. If proper repairs to correct the problem that caused the code(s) to be set are not made, the code(s) will appear again and the check engine light will illuminate as soon as the problem that cause the DTC to set manifests itself.

On the diagnostic function selection screen, tap **Clear Fault Code**, the following screen will appear.



Tap **YES**, the system will automatically delete the currently existing trouble code.

Note: After clearing, you should retrieve trouble codes once more or turn ignition on and retrieve codes again. If there are still some trouble codes in the system, please troubleshoot the code using a factory diagnosis guide, then clear the code and recheck.

D. Read Data Stream

This option lets you view and capture (record) real-time Live Data. This data including current operating status for parameters and/or sensor information can provide insight on overall vehicle performance. It can also be used to guide vehicle repair.

Caution: If you must drive the vehicle in order to perform a troubleshooting procedure, ALWAYS have a second person help you. Trying to drive and operate the diagnostic tool at the same time is dangerous, and could cause a serious traffic accident.

Note: The real time (Live Data) vehicle operating information (values/status) that the on-board computer supplies to the tool for each sensor, actuator, switch, etc. is called Parameter Identification Data (PID).

On the diagnostic function selection screen, tap **Read Data Stream**, the following screen will appear.



On-screen Buttons:

Select Page: Tap to select all items of the current page.

<u>Select All:</u> Tap to select all items. To select certain data stream item, just check the box before the item name.

Unselect: Tap to deselect all data stream items.

OK: Tap to confirm and jump to the next step.

After selecting the desired items, tap **OK** to enter the data stream reading page.

Data Stream					•	P.
DEMO V15.32 + FORO + System Solarnon + 1 Name	CM (Provertion Control	Value	1	English	Metr	ic.
Accelerator Pedal Position Sensor 1		1.11		v	~	2
Accelerator Pedal Position D		19.01		5		2
Accelerator Pedal Position Sensor 2		0.57		Ŷ	*	2
Accelerator Pedal Position E		21.18		5		1
Barometric Pressure		99.5		kPa	×	1
FORD F 350 2012 VN 1F 78W3D T9CE8000000	Compare Sample	Save Sample	Graph	Réport	Rec	bird

🛃 Notes:

1. Tap **1**, the following popup will appear.



Here the user can set different display style for each selected item.

indicates sticky top. If it is tapped, it will change into \uparrow . On the data stream display screen, the data stream item with \uparrow will be shown on the top of the selected data stream list. To remove it from the top of the list, just tap it again.

B indicates this item will be displayed in Bold.

A indicates this item will be displayed in Red.

- 2. Tap English or Metric to switch the measurement unit.
- If the value of the data stream item is out of the range of the standard (reference) value, the whole line will display in red. If it complies with the reference value, it displays in blue (normal mode).
- 4. The indicator 1/X shown on the bottom of the screen stands for the current page/total page number. Swipe the screen from the right/left to advance/return to the next/previous page.

There are 3 types of display modes available for data viewing, allowing you to view various types of parameters in the most suitable way.

- <u>Value</u> This is the default mode which displays the parameters in texts and shows in list format.
- ✓ <u>Graph</u> Displays the parameters in waveform graphs.
- ✓ <u>Combine</u> This option is mostly used in graph merge status for data comparison. In this case, different items are marked in different colors.

On-screen Buttons:

Graph(Single): Tap to view the parameter in waveform graph.

Data Stream		A 6 P
DEMO V1532 × FORD × System Soluction & PCM (Provertion Com Name	vent kalentuur) Value	Unit
Accelerator Pedal Position Sensor 1	0.78	V
24		
4		10
2.8		<
LAM a		
-Mm-		1

 <u>Min/Max</u>: Tap to define the maximum / minimum value. Once the value goes beyond the specified value, the system will alarm.

Graph: Tap to view the parameters in waveform graphs.

Data Stream			🔒 🖶 🕞
DEMO V15.32 × FORD × Sysum Se	kiezum is PEM (Powertnike Commit	Londoniy)	
Accelerator Pedal Pourior E 15.69(%)	Accelerator Peptal Position Series 1 0.78(V)	Acceleration Pedal Position D 15.69(%)	Accelerator Pedal Prosingel Serrace 2 0.39(V)
fffr	in.	A.	me
hand drakat drakat drakat dra			
99.5(kPa)	Carlot Feder Positive D(%)	Ourth Petal Tourish Switch	2.8(deg)
Looppersoner.			-
Dectronic Throatie Motor Pullewellin Comm. 1 -14.41(%)	Augostitive Einstein Canadae Pargel Valve 7.42(%)	Evaporative System Alteritor Evaluated. Yes	Full Loves 79.22(%)
MIL	and and a		-
FORD F-350 2012 VIN 1FT8W3DT9CE800000	Save Sample	Combine Value	Report Record

• <u>Combine</u>: This option is mostly used in graph merge status for data comparison. In this case, different items are marked in different colors (maximum 4 items can be displayed on the same screen simultaneously). If the graph is more than one page, swipe the screen from the left to jump to the next page.



- <u>Value</u>: Switches the current graph display mode to the Value display mode.
- <u>Customize</u>: Tap
 , a pull-down list of the data stream items appears on the screen. Select / deselect the desired items, and then screen will display / remove the waveforms corresponding to these items immediately.

Data Stream DEMO V1532 > FORD > System Sel	ection a DEM (Dissortion) Council &	Anida the V	Maximum 12 data streams can be selected.		
Accelerator Pedal Position E 21.18(%)	Accelerator Pedal Position Sensor 1 1.11(V)	Act		Accelerator Pedal Position Sensor 1	
Lowerson	-	2		Accelerator Pedal Position D	
Bardmetric Pressure 99.5(kPa)	Cliebsh Predail Possilier D(%)	d.		Accelerator Pedal Position Sensor 2	
the second second		13		Accelerator Pedal Position E	
Dectronic Throffle Motor Pullewidth Comm. Di 13.89(%)	epositive Errission Caretter Purge Valve 17.2(%)	Evepore		Barometric Pressure	
1	1	-		Clutch Pedal Position	
FORD F-350 2012 VIN 1FT8W30T9CE800000	Save Sample	Cor		Clutch Pedal Position Switch	

Compare Sample: Tap to select the sample DS file.

All the values you customized and saved in process of DS sampling will be imported into the **Standard Range** (See below) column for your comparison.

Note: Before executing this function, you have to sample the values of data stream items and save it as a sample Data Stream file.

Data Stream				e 🖻
DEMD V15.32 × FORD × System Selection A PD Name	M (Provertnan Countril Mariana Value	Standard Range(Data Stream Sample)	English	Metric
Accelerator Pedal Position Sensor 1	0.78	0.78 - 1.8	v	* 🜌
Accelerator Pedal Position D	22.75	10-27.84		
Accelerator Pedal Position Sensor 2	0.39	0.23 - 0.57	v.	* 📶
Accelerator Pedal Position E	19.89	0-24.71	4	2
Barometric Pressure	99.5	52.5-99.5	kPa	× 🔊
FORD F-350 2012 VIN 1F78W3D19CE800000	Compare Sample Serve	Sample Graph	Report	Incard

<u>Report</u>: Tap to save the current data in text format. All reports are saved in **Report -> Health Reports**. For details on report operations, please refer to Chapter 9.2.1.

<u>Record</u>: Tap to start recording diagnostic data. Recorded live data can serve as valuable information to help you in troubleshooting of vehicle problems.

Data Stream		1.11	6 (F)
DEMO V15-32 + FDRD + system Selection + PEAK (Provertin	an Egunna Madalig)		
Name	Value	English	Metric
Accelerator Pedal Position Sensor 1	'nni	v	* 🜌
Accelerator Pedal Position D	19.61	8	
Accelerator Pedal Position Sensor 2	0.57	v	- 2
Accelerator Pedal Position E	21.18	÷	2
Barometric Pr	nd	****00·02	× 📶
FORD F-350 2012	Sanche Deep Semple G	raph Report	Healed

Tap () to end recording and save it. The saved file follows the naming rule: It begins with vehicle type, and then the product S/N and ends with record starting time (To differentiate between files, please configure the accurate system time). All diagnostic records can be replayed from **Report -> Recorded Data**.

Save Sample: This item enables you to customize the standard range of live data stream items and save it as DS sample file. Each time you run the data stream items, you can call out the corresponding sample data to overwrite the current standard range.

Tap it to start recording the sample data (Note: Only data stream items with measurement units will be recorded), the following screen will appear:

Data Stream 0/MO V15-10 = F100 = System Selection 6	DCAI (Drawething Country) Manhaire)			e	P
Name	Value Value	E	nglish	Metr	ic.
Accelerator Pedal Position Sensor 1	Q 7E		v	*	2
Accelerator Pedal Position D	15.6		1		1
Accelerator Pedal Position Sensor 2	04		.v.	*	2
Accelerator Pedal Position E	0		ъ.		1
Batometric Pre	Sample Recording		^{a:P2} 00:03	~	1
FORD F 350 2012 VN 1F 78W3D 79 CEB00000	Company Samole Tany Sam	nois Graph	Report	19mg	and

Once the recording process is complete, tap
to stop it and navigate to the data revision screen.

Confirm Sample DS					n 🔿	17
DEMO V13-30 + FORM + Systems Selection + PEM		uiz)				
Name	Min Value		Max Value		Linin	
Accelerator Pedal Position D	0.0	0	27.84	0	8	
Accelerator Pedal Position E	0.0	0	24.71	0	3	
Accelerator Pedal Position Sensor 1	0.78	۵	1.11	0	v	
Accelerator Pedal Position Sensor 2	0.39	٥	0.57	0	v	
Barometric Pressure	99.5	0	99.5	0	Кра	
FORD F-350 2012 VN 1FTBW3D 1502600000					Sa	Ve

Tap the Min./Max. value to change it. After modifying all desired items, tap **Save** to save it as a sample DS file. All DS files are stored in **User Info -> Data Stream Sample**.

6.3 Remote Diagnose

This module helps repair shops or mechanics to diagnose a remote vehicle, and launch instant messages, allowing for improved efficiency and faster repairs.

Tap Remote Diagnose on the Job menu, the screen appears blank by default.

Contacts Contac	(1)
Contast	
Remote 5	

1	Home Button	Navigate to the Job menu screen.
2	Search Bar	Directly input the username of the tool for searching, and then tap the desired one to add it into Contacts list.
3	Messages Tab	A red dot will appear indicating a received message.
4	Contacts Tab	Enter the friend list.
5	Remote Switch	Your technician can control your tool remotely once the switch is ON.

6.3.1 Add Friends

Tap Contacts. By default it appears blank.

In the search bar, input the partner's username and tap **Search** to start searching.

The partner must be the users who have registered specific diagnostic tools. They may be the following:

- Workshop
- Technician
- golo users

Once the result matches the keyword, the following screen will appear:

Messa	gési				
	Q, yread	0	5	yt985491588000	-
0	Internet search	results			
Messag es	yt986491588	SOOO - Lamonte Chargement			
	yt986491547	7400 • -			
Sartas	y1986491555	7200 a Benche dispose			
	yt986491554	1400 ·			
B	y1986491441	1600 - Innuts degrees			
Remote	YT98609008	1900 Securit Segure	٢		(i)(+)

Here you can tap **Remote Diagnose** to launch remote diagnostics directly or choose to add the partner into the Contacts list.

Tap the desired name from the list, the following screen will appear:

Messag	ges					
	Q, yrma	0	<	yt986491588	000	Lionor
0	Internet search	results				
Messag	yt986491588	000 · Securit degrees				
	yt986491547	400 - Secula dagona	ľ.			
Contact	yt986491559	200 • Securit degrees				
	y1986491554	400 ·	0	 -	-	
Remote	y1986491441	600 ·	8	87		ත
Hemote	YT98609008	1900 Servit Gegreer		 -	Contract of Contra	-Cana

Tap Add friend to send your request.

Once the partner receives the request, a beep will sound. Tap Messages:

- Once the partner agreed your request, he/she will automatically be listed in the Contacts tab.
- If a technician sent you a friend request, tap Agree and his/her name will appear in the Contacts list. Or tap Ignore to ignore this request.

messag	es			1
ined .	-	Verification Information		-
(A)	Evon Lam Evon		Ignore	Agree

6.3.2 Start Instant Messaging

The I/M (Instant Messaging) function is open to all users who had the diagnostic tool equipped with this module.

After adding your friends, tap the desired one's photo to enter the following screen:



Tap the input field and use the on-screen keyboard to send the text message.

- Tap (i)) to send the voice message.
- Tap 🙄 to send the emoj.
- Tap (+) to call out more function options.



File: Choose diagnostic reports or local files to send.

Picture: Choose screenshots or pictures to send.

Remote Diagnose: To start a remote diagnostic session. For details, refer to

Chapter 6.3.4.

Camera: Open camera to take pictures.

6.3.3 Launch Remote Diagnosis (Device-To-Device)

The tool is allowed to initiate remote diagnosis with other diagnostic tools, which are equipped with this module.

On the function option selection screen, tap **Remote Diagnostic**, the following pull-down menu will appear:



These options are defined as follows:

Actions	Results		
Request control remote device	 Request to control the partner's device remotely to help him diagnose the vehicle. Notes: In process of remote diagnosis, tap the button to send a voice message. Once vehicle diagnosis is complete, a report will be created. Input your comments on this report, and then tap Send Report to send it to the partner. 		





6.3.4 Launch Remote Diagnosis (Device-To-PC)

User also can ask for remote control from a PC client technician.



Tap Remote, the following screen will appear:

Remot	e Diagnose	
	Allow device to be connected to the WEB client Remote Diagnose device.	To request a necheixaer for Remote Disprose, perform as follows:
Messag		1, Fun on the WEB Remote Deeptone switch and choose the sar model to be
	and the second second	shegranet
	After the button is enabled, your	2. The remote technician logs in to the WEB Remote Disgnate platform http://
	device can be controlled remotely by	remote #431 com, inputs the device 5/N 588750000002, and remotely contracts
	a PC client technician	to your device for diagnosis
Contact		Note Settion gas recom addres referring agond and portion other it grown line
		in reiter net talaftect Elemate Dagman
•		
ternobe		legged land

- 1. Slide the switch to ON so that the partner can find and connect to this device while using the PC.
- Notify the partner of the PC client website http://remote.x431.com. When the partner accesses the link, the PC displays as below:

Note: Before processing remote diagnosis, please make sure the tool is properly connected to the vehicle.

Real-time r system d	
Login	Register
۵	
A	
Remember Me	Forget Password?
Remember Me	-

3. Tell the partner to input his own official technician account and password, and then tap **Login** to navigate to the following figure.



4. Tell the partner to enter the Serial Number provided by you, and then tap **Start remote diagnosis** to control your device remotely.

In process of remote diagnosis, please note the following things:

- 1) You are not suggested to execute any actions.
- The partner is not allowed to save any diagnostic reports or records on your tablet.

Once the session is complete, a remote diagnostic report will be automatically generated.

6.4 Feedback

This function enables you to feedback the diagnostic issues to us for analysis and troubleshooting.

Tap Feedback, and tap OK to enter into the vehicle diagnostic record page.

A. Feedback

Tap the target vehicle to enter the feedback page.

B. History

Tap it to view the diagnostic feedback logs which are marked with different color indicating the process status of the diagnostic feedback.

C. Offline list

Tap it to enter the diagnostic feedback offline list page. Once the tablet gets a stable network signal, it will be uploaded to the remote server automatically.

6.5 Diagnostic History

This function enables users to directly get access to the previously tested vehicle's diagnostic records in details, so users can resume from the last operation, without starting from scratch.

Tap **Diagnostic History** on the Job menu screen, all diagnostic records will be listed on the screen in date sequence.

Diagnostic H				Senai Nurr	nber: 98934000011
2020/05 (1)		DEMO	VIN 1FTBWSDT9CEB00000 DEMO	Number of diagnostic systems: 17 DTC;3 2020-05-14.03-47.00PM	QUICK ACCESS
		DEMO	VIN 1FT8WSDT9CE800000 DEMO	Number of diagnostic systems: 17 DTC:3 -2020-05-14-03-26-48PM	QUICK ACCESS
	-		DEMO		Fundation

- Tap certain vehicle model to view the details of the last diagnostic report.
- To delete certain diagnostic history, select it and then tap **Delete**. To delete all historical records, tap **Select All** and then tap **Delete**.
- Tap **Quick access** to directly navigate to the function selection page of last diagnostic operation. Choose the desired option to proceed.

7 Service (Reset) Function

This module provides an easy dial to quickly access the most commonly performed service functions. It offers coding, reset, relearn and more service functions, to help vehicles get back to functional status after repair or replacement.

7.1 Oil Reset Service

This function enables you to reset the oil service for the engine oil life system, which calculates an optimal oil life change interval depending on the vehicle driving conditions and weather events.

It needs to be performed in the following cases:

- 1. If the service lamp is on, run car diagnostics first for troubleshooting. After that, reset the driving mileage or driving time, so as to turn off the service lamp and enable a new driving cycle.
- 2. If the service lamp is not on, but you have changed the engine oil or electric appliances that monitor oil life, you need to reset the service lamp.

7.2 Electronic Parking Brake Reset

This function enables you to reset the brake pad after replacing the brake pad.

It needs to be performed in the following cases:

- 1. The brake pad and brake pad wear sensor are replaced.
- 2. The brake pad indicator lamp is on.
- 3. The brake pad sensor circuit is short, which is recovered.
- 4. The servo motor is replaced.

7.3 Steering Angle Calibration

This function enables you to reset the steering angle, after replacing the steering angle position sensor, replacing steering mechanical parts (such as steering gearbox, steering column, end tie rod, steering knuckle), performing four-wheel alignment, or recovering car body.

7.4 ABS Bleeding

This function allows you to perform various bi-directional tests to check the operating conditions of Anti-lock Braking System (ABS).

It needs to be performed in the following cases:

- 1. When the ABS contains air.
- 2. When the ABS computer, ABS pump, brake master cylinder, brake cylinder, brake line, or brake fluid is replaced.

7.5 Tire Pressure Monitor System Reset

This function enables you to quickly look up the tire sensor IDs from the vehicle's ECU, reset tire pressure and turn off the tire pressure MIL.

It needs to be performed in the following cases:

Tire pressure is too low, tire leaks, tire pressure monitoring device is replaced or installed, tire is replaced, tire pressure sensor is damaged, and tire is replaced for the car with tire pressure monitoring function.

7.6 Gear Learning

This function enables you to perform tooth learning for the car, to turn off the MIL.

It needs to be performed in the following cases:

- 1. After the engine ECU, crankshaft position sensor, or crankshaft flywheel is replaced.
- 2. The DTC 'tooth not learned' is present.

7.7 Injector Coding

This function enables you to write injector actual code or rewrite code in the ECU to the injector code of the corresponding cylinder, so as to more accurately control or correct cylinder injection quantity.

It needs to be performed in the following cases:

After the ECU or injector is replaced.

7.8 Battery Maintenance System Reset

This function enables you to perform a resetting operation on the monitoring unit of vehicle battery, in which the original low battery fault information will be cleared and battery matching will be done.

It needs to be performed in the following cases:

- 1. The main battery is replaced.
- 2. The battery monitoring sensor is replaced.

7.9 Diesel Particulate Filter (DPF) Regeneration

This function enables you to clear PM (Particulate Matter) from the DPF filter through continuous combustion oxidation mode (such as high temperature heating combustion, fuel additive or catalyst reduce PM ignition combustion) to stabilize the filter performance.

It needs to be performed in the following cases:

- 1. The exhaust back pressure sensor is replaced.
- 2. The PM trap is removed or replaced.
- 3. The fuel additive nozzle is removed or replaced.
- 4. The catalytic oxidizer is removed or replaced.
- 5. The DPF regeneration MIL is on and maintenance is performed.
- 6. The DPF regeneration control module is replaced.

7.10 Electronic Throttle Position Reset

This function enables you to make initial settings to throttle actuators and returns the *learned* values stored on ECU to the default state. Doing so can accurately control the actions of regulating throttle (or idle engine) to adjust the amount of air intake.

7.11 EGR Adaption

This function is used to learn the EGR (Exhaust Gas Recirculation) valve after it is cleaned or replaced.

7.12 Gearbox Matching

This function can complete the self-learning of the gearbox and improve the shift

quality.

It needs to be performed in the following cases:

When the gearbox is disassembled or repaired.

7.13 AdBlue Reset (Diesel Engine Exhaust Gas Filter)

After the diesel exhaust treatment fluid (car urea) is replaced or filled up, urea reset operation is required.

7.14 Transport Mode

To lower vehicle power consumption, user may perform the following operations: limit vehicle speed, not wake up the network for door open and disable remote key etc. In this case, deactivating transport mode is needed to recover vehicle being normal.

7.15 Windows Calibration

This function is used to perform door window matching to recover the ECU initial memory, and recover the automatic ascending and descending function of power window.

8 Software Update

This module enables you to update the diagnostic software & App and frequently used software.

8.1 Update Diagnostic Software & APP

Go to Software Update on the Job Menu and tap the Car model tab.

The Car model tab displays a list of vehicle diagnostic software.

Software Update						11 A
Car readel (MUD)					_	ner; 1988770000004
Vehicle	Current Version	Update Version	Size		Update conte	int
Firmware upgrade program	V20.33	V20.34	118.0 K	Software pp	imization and	apdate
02-1 Scopebox		V1.0.30	50.3 M	Software opt	imization and i	apdate
Adblue Resel		910.10 *	23.6 M		nction of Adbl. AR, LANDROVE	
			Refresh	Unselect	Update	Renewals

Tap **Update** to start downloading. Once download is finished, the software packages will be installed automatically.

8.2 Update IMMO&IMMO PROG Software

If the user only intends to update the IMMO&IMMO PROG software, go to Software Update and tap the **IMMO** tab.

Generation INIMO				Senal Number: 98877000000
Vehicle	Current. Version	Update Version	Size	Update content
		V10.01 -	1.9 M	Software optimization and update
		V10.01 -	93M	Support the anti-theft function of Qin,Tang,Song,Yuan,F3,Suru(Sinu,E 5,E6,F0,F6,36,57,e series and other mo
Cowin_IMMO		V10.01 -	2.4 M	Software optimization and update
			Refresh	Unselect Update Renewals

Tap **Update** to start downloading. Once download is finished, the software packages will be installed automatically.

8.3 Renew Subscription

If the software subscription is due or expires, the system will prompt you to renew your subscription.

Tap **Renewal** on the bottom of the screen to enter the payment screen. There are three ways available for you to make payment: PayPal, Subscription Renewal Card (*need to buy it from the local dealer where you purchased the tool) and Credit Card.

Software Update		
SN 989280000017 Software Expendion Date		
Software Name		
1. PayPal Pay		
LAUNCH		
Software Update Renewal	Fee:	PayPal
2 Subscription Renewal Card Pay		
LAUNCH		
Phease buy it from local dealer, after activated year or two years.	d you can use it free within one	SUBSCRIPTION RENEWAL CARD
3. Credit Card		
LAUNCH		
and the second sec	Sec	Contraction of the second

1. Using PayPal

- 1. Select *PayPal*, and then follow the on-screen instructions to finish the transaction.
- 2. After payment, go to update center to update the diagnostic software.

2. Using Subscription Renewal Card

1. Select Subscription Renewal Card.

LAUNCH	
LAUN	
	-
- District	
SUBMIT	

- 2. Input the 24-digit pin code of Subscription Renewal Card and then tap Submit to finish the renewal.
- 3. Go to update center to update the diagnostic software.

3. Using Credit Card

- 1. Select *Credit Card*, and then follow the on-screen instructions to finish the transaction.
- 2. After payment, go to update center to update the diagnostic software.
9 Other Modules

9.1 Toolbox

9.1.1 BST360 (Battery Tester)

This module allows you to fix battery detection faster and easier. It needs to work with the specific Bluetooth battery tester (sold separately).

For more details, please refer to the User Manual included with the module.

9.1.2 Videoscope

This module allows you to check those unseen parts of engine, fuel tank, braking system. It needs to work with the compatible Videoscope device (sold separately).

For more details, please refer to the User Manual included with the module.

9.1.3 S2-2 Sensorbox

This module is specially designed to diagnose and simulator vehicle sensor faults quickly and conveniently. It needs to work with the compatible S2-2 Sensorbox (sold separately).

For more details, please refer to the User Manual included with the module.

9.1.4 S2-2 Multimeter

This module allows you to measure the physical parameters such as voltage, resistance, frequency etc. It utilizes the same hardware as the S2-2 Sensorbox.

For more details, please refer to the User Manual included with the S2-2 Sensorbox.

9.2 User Info

This function allows users to manage personal information and VCI.

9.2.1 My Report

This option is used to view, delete or share the saved reports.

Tap **Report**, there are total 3 options available.

In case the DTC result is saved <u>on Read Trouble Code page</u>, the files will be listed under **Health Reports** tab.

LAUNCH

If user records the running parameters <u>while reading data stream</u>, the tablet will save the file which appears under **Recorded Data** tab.

Remote Reports lists all diagnostic reports generated in process of remote diagnosis.

9.2.2 VCI

This option allows you to manage all your activated VCI devices.

If several VCI devices are activated on this tool, a list of VCIs will be displayed on the screen. Once you choose the VCI that belongs to other account, you have to log out, and then input the right account to continue.

9.2.3 VCI Management

This option is used for the tablet to deactivate pairing up with the VCI device via Bluetooth.

9.2.4 Activate VCI

This item lets you activate the VCI device in case you ignore the Activate VCI step in process of the product sign-up.

Activate Connector	.
Serial Number	
Activation Code	
	Where is my activation code

Input the Serial Number and Activation Code, and then tap **Activate** to activate the VCI.

9.2.5 Firmware Fix

Use this item to upgrade and fix diagnostic firmware. During fixing, please do not cut power or switch to other interfaces.

9.2.6 My Order

This item allows you to check the status of all your orders.

9.2.7 Subscription Renewal Card

This item is used to check the status of the subscription renewal card.

Input the 12-digit subscription renewal card number. Tap **Search** to get the search result.

9.2.8 Profile

Use this item to view and configure personal information.

Profile	
	-
Us	emame:a985190018060
Nickname	a985190018060 >
Gender	G 1
Country	China >
Email	haijun.peng@cnlaunch.com(unbound) >
Free Upgrade Period	>

- Tap the user image to change it.
- Tap > next to Upgrade Period to check the due date of all diagnostic software.

9.2.9 Change password

This item allows you to modify your login password.

9.2.10 Settings

It enables you to make some application settings and view software version information etc.

1. Units

It is designed to configure the measurement unit. Metric System and English System are available.

2. Shop Information

This option lets you define your shop information. It mainly includes Workshop,

LAUNCH

Address, Telephone, Fax and License Plate.

After inputting, tap Save.

Once you saved the shop information, it will be entered automatically in the Add *Information* box every time you save the diagnostic report.

3. Printer Set

This option is designed to establish a wireless connection between the tablet and the Wi-Fi printer (sold separately) while performing printing operations.

The App is compatible with the *LAUNCH[®] Wi-Fi Printer* (sold separately) and *System* (external printer).

For LAUNCH® Wi-Fi printer, follow the steps below to connect the printer.

1. Tap Printer Set.



A. <u>If it is the first time you have operated this printer</u>, please proceed the following:

 For initial use, you are suggested to reset the printer: Press and hold MODE & FEED for 8 seconds, the following resetting command will be printed out:

```
at + default = 1
ok
at + reboot = 1
rebooting...
```

2. Tap Reset to configure Wi-Fi printer.

Step 1: Connect the printer:

Tap Scan to start scanning and select the desired printer hotspot named with

X-431PRINTER-XXXX (XXXX stands for 4 characters), and then tap **Connect** to enter Step 2.

Step 2: Join the Wi-Fi printer into LAN:

Tap **Scan** to select the desired local Wi-Fi network from the list, and type in the security password (If it is an open network, password is not required), and then tap **Confirm**.

 Once the Wi-Fi network of the printer is connected and the printer is found, tap **Printing test** to test the printing.

Now the Wi-Fi printer is ready for printing.

If the printer is not found, please reset the printer to default factory settings (refer to Step 2 for details) and check whether the current device and the printer are on the same LAN.

B. If you have configured the Wi-Fi printer to the LAN:

2. Tap Connect to Printer:

a). If the local network remains as it is, tap **Test Print** directly to test the printing.

b). If the local network changes, you have to reset the Wi-Fi printer.

For other Wi-Fi printers,

Before printing, make sure the following conditions are met:

- The Wi-Fi printer is powered on and working normally.
- The print service plug-in associated with the printer is already installed on the tablet (Go to Google Play or use the Browser to download and install it).

Follow the steps below to proceed:

- 1. Set the default printer as System.
- Go to Other Modules -> Tablet Settings -> WLAN, set the WLAN switch to Off.
- On the report details page, tap Image: Contract of the report details page in the report details page.



- 4. Touch with the screen of the screen.



5. Select All Printers -> Add printer and enable the installed printer service, the system starts searching for all available Wi-Fi printers of the brand.

All proteina-	Latter	÷	
	1	and the second se	

6. Select the desired Wi-Fi printer from the list. If the chosen Wi-Fi printer

hotspot is open, the tablet can connect it directly. If it is encrypted, a password may be required. Refer to the Wi-Fi printer user manual to get the default password.

- 7. Now the printer is ready for printing.
- 8. Alternatively, you can also choose **Save as PDF** to save the current diagnostic report as a PDF file for later printing.

4. Orientation

The option is used to set the screen display orientation.

5. Clear Cache

This option allows you to clear the App cache. Clearing the cache will restart the App.

6. About

The software version information and disclaimer are included.

7. Device Account Management

This option is used to manage the sub-accounts. The added sub-account allows the VCI connector to be used by different users to log in the tool, which is convenient for multiple VCIs to perform diagnostic service at the same time.

The newly added sub-account has a one-year validity period. After the expiration, the VCI bound to the sub-account cannot be used and the sub-account will no longer enjoy the rights and interests of the main account. The main account can modify the validity period of the sub-account.

There are two types of sub-accounts: one is an existing account and the other is a newly created account. The main account has the functions of adding and removing sub-accounts, the sub-account can also be unbound from the main account.

Tap **Device account management**, the following screen will appear:



Tap Add sub account, the following popup will appear:

Add sub account		
already ha and passw	s an account, please enter the vord.	e user name
Please ent	er username	0
Please *	enter password	
Please ent	er the remark name	
	ADD IMMEDIATELY	
	C	reate sub use

- If you already have an account, please enter the user name and password. After inputting, tap **Add Immediately** to add it as a sub-account.
- If you have not registered any account, tap Create sub user. Enter the user name and password, and then tap Add Immediately to add it as a sub-account.

After adding the sub-account, the following screen will appear:



To unbind it from the main account, tap **Remove**. To revise the validity period, tap **Change**.

8. Login/Logout

To logout the current user ID, tap Logout.

To login the system again, tap Login.

9.2.11 Diagnostic Software Clear

This item allows you to hide/clear the diagnostic software that is not frequently used.

Note: Removing software may completely delete the software from the tablet. If some software is not used and the tablet runs out of space, you can use this feature to remove it.

10 FAQ

1. How to save power?

- · Please turn off the screen while the tool keeps idle.
- Set a shorter standby time.
- · Decrease the brightness of the screen.
- If WLAN connection is not required, please turn it off.
- Disable GPS function if GPS service is not in use.

2. Communication error with vehicle ECU?

Please confirm:

- 1. Whether diagnostic connector is correctly connected.
- 2. Whether ignition switch is ON.
- 3. If all checks are normal, send vehicle year, make, model and VIN number to us using Feedback feature.

3. Failed to enter into vehicle ECU system?

Please confirm:

- 1. Whether the vehicle is equipped with this system.
- 2. Whether the VCI dongle is correctly connected.
- 3. Whether ignition switch is ON.
- 4. If all checks are normal, send vehicle year, make, model and VIN number to us using Feedback feature.

4. What to do if the language of vehicle diagnostic software does not match the system language?

English is the default system language of the tool. After the system language is set to the preference language, please go to the update center to download the vehicle diagnostic software of the corresponding language.

If the downloaded diagnostic software is still displayed in English, it indicates that the software of the current language is under development.

5. How to retrieve the login password?

LAUNCH

Please follow below steps to proceed in case you forgot the login password:

- 1. Tap the application icon on the home screen to launch it.
- 2. Tap **Login** on the upper right corner of the screen.
- 3. Tap Retrieve password.

Warranty

This warranty is expressly limited to persons who purchase LAUNCH products for purposes of resale or use in the ordinary course of the buyer's business.

LAUNCH electronic product is warranted against defects in materials and workmanship for one year (12 months) from date of delivery to the user.

This warranty does not cover any part that has been abused, altered, used for a purpose other than for which it was intended, or used in a manner inconsistent with instructions regarding use. The exclusive remedy for any automotive meter found to be defective is repair or replacement, and LAUNCH shall not be liable for any consequential or incidental damages.

Final determination of defects shall be made by LAUNCH in accordance with stipulated procedures.

Order Information

Replaceable and optional parts can be ordered directly from your authorized tool supplier. Your order should include the following information:

- Quantity
- Part number
- Item description

Customer Service

If you have any questions on the operation of the unit, please contact local dealer, or customer service center:

Tel: 86-755-25938674

E-mail: DOD@cnlaunch.com