

Thank you for purchasing AUTEL diagnostic tool. Manufactured to a high standard, our tool will, if used according to these instructions and properly maintained, give you years of trouble-free performance.

Getting Started




IMPORTANT: Before operating or maintaining this unit, please read the quick guide and user manual carefully, pay extra attention to the safety warnings and precautions. Use this unit correctly and properly. Failure to do so may cause damage and/or personal injury and will void the product warranty.

1



- Scan QR Code to visit our website at www.autel.com.
- Create an Autel ID and register the product with device's SN and password.

2



- Insert the MaxiVCI Mini into the vehicle's DLC, which is generally located under the vehicle dash.

3



- Long press the Lock/ Power button to turn on the Diagnostic Tablet.

4



- Pair up the Diagnostic Tablet with the VCI device via BT to establish a communication link.
- When the VCI device is properly connected to the vehicle and the Diagnostic Tablet, the VCI status button at the bottom bar on the display screen shows a green tick at the corner. This indicates your Diagnostic Tablet is ready to start vehicle diagnosis.

 Please download the **Maxi PC Suite** from www.autel.com > *Support & Updates* > *Firmware & Downloads* > *Update Client*, and install to your windows-based computer.

Software Update



IMPORTANT: Make sure the Diagnostic Tablet is connected to the Internet and the Tablet has sufficient battery or is connected to a power source.

- Tap the **Update** application button from the Diagnostics Job Menu and the Update screen displays.
- Check all available updates: a) if you want to update **all** the items, tap the **Update All** button; b) if you want to update one or some of the items, tap the **Update** button on the right column of the specific item(s).
- Tap **Pause** to suspend the updating process. Tap **Continue** to resume.
- When the updating process is completed, the software will be installed automatically. The previous version will be replaced.

MaxiVCI Mini Firmware Update

- Connect the MaxiVCI Mini to a PC using a USB cable.
 - Run the **PC Suite** on the computer which is installed after the installation of **Maxi PC Suite** and click MaxiVCI Mini icon on the Device Selection window.
 - The driver will automatically detect the updates of the device.
 - Click **Update** to complete the operation if an update is available.
- Or
- Connect the MaxiVCI Mini with the Diagnostic Tablet using a USB cable.
 - Tap **VCI Manager** from the Diagnostics Job Menu, and then tap **Update** to complete the operation if an update for the MaxiVCI Mini is available.

Wireless Data Printing

Print via PC



IMPORTANT: Make sure the Diagnostic Tablet is connected to the same network with the computer, either via Wi-Fi or LAN, and the computer is connected to a printer.

- Run the **MaxiSys Printer** on the computer which is installed after the installation of **Maxi PC Suite**.
- Click **Test Print** to make sure the printer is working successfully.
- Tap **Print** on the toolbar of the Diagnostic Tablet. A temporary document will be created and sent to the computer.
 - If the **Auto Print** option in the MaxiSys Printer is selected, the MaxiSys Printer will print the received document automatically.
 - If the **Auto Print** option is not selected, click **Open PDF File** to view all the temporary files. Select the file(s) you want to print and click **Print**.

Print via APP

If a Wi-Fi printer is available, please purchase a Wi-Fi printer APP and install it onto your Diagnostic Tablet. By a simple click on the **Print** button of a saved file on the Diagnostic Tablet, the file will be printed automatically.

For service and support, please contact us.

<http://pro.autel.com> / www.autel.com / support@autel.com
0086-755-86147779 (China HQ) / 1-855-288-3587/1-855-AUTELUS (North America)
0049 (0) 61032000522 (Europe) / (+507) 308-7566 (South America) / 03 9480 2978 / +61 476293327 (Australia)

© Autel Intelligent Technology Corp., Ltd. All Rights Reserved.